


**BWL CORE BARREL SPARE PARTS KIT**



	ITEM DESCRIPTION	PART NUMBERS
<b>1-18</b>	<b>BWL CORE BARREL SPARE PARTS KIT</b>	<b>14-00-140</b>
<b>1</b>	SPEARHEAD POINT	16-03-001
<b>2</b>	COMPRESSION SPRING	16-03-002
<b>3</b>	DETENT PLUNGER	16-03-003
<b>4</b>	SOLID DOWELL 7/16" x 1"	16-03-005
<b>5</b>	SPRING DOWELL 3/8" x 1 5/8" - 2 NOS.	14-03-003
<b>6</b>	BWL LATCH - 2 NOS.	14-03-005
<b>7</b>	SOLID DOWELL 3/8" x 1 1/4"	14-03-006
<b>8</b>	ADJUSTING HEX NUT	14-03-008
<b>9</b>	SHUT OFF VALVE - 2 NOS.	14-03-010
<b>10</b>	THRUST BEARINGS - 2 NOS.	14-03-012
<b>11</b>	BEARING SPINDLE	14-03-014
<b>12</b>	NYLOCK NUT , 5/8" UNC	14-03-017
<b>13</b>	GREASE FITTING	16-03-024
<b>14</b>	RING STOP	14-03-021
<b>15</b>	CORE LIFTER	14-03-022
<b>16</b>	CORE LIFTER CASE	14-03-023
<b>17</b>	RING LANDING	14-02-003
<b>18</b>	STABILIZER RING	14-02-006