


NWL-LI CORE BARREL SPARE PARTS KIT



	ITEM DESCRIPTION	PART NUMBERS
1-23	NWL-LI CORE BARREL SPARE PARTS KIT	16-00-140
1	SPEARHEAD POINT	16-03-001
2	COMPRESSION SPRING	16-03-002
3	DETENT PLUNGER	16-03-003
4	SOLID DOWELL 7/16" x 1"	16-03-005
5	SPRING DOWELL 1/2" x 2" - 2 NOS.	16-03-007
6	NWL-LI LATCH - 2 NOS.	16-03-009
7	SOLID DOWELL 1/2" x 1 1/2"	16-03-010
8	STAINLESS STEEL BALL 22 mm	16-03-014
9	LANDING INDICATOR BUSH O RING	16-03-016
10	LANDING INDICATOR BUSH	16-03-015
11	LANDING SHOULDER	16-03-012
12	ADJUSTING HEX NUT	16-03-017
13	SHUT OFF VALVE - 2 NOS.	16-03-019
14	THRUST BEARING	16-03-021
15	BEARING SPINDLE	16-03-023
16	THRUST BEARING	16-03-025
17	NYLOCK NUT, 3/4" UNC	16-03-027
18	GREASE FITTING	16-03-024
19	RING STOP	16-03-031
20	CORE LIFTER	16-03-032
21	CORE LIFTER CASE	16-03-033
22	RING LANDING	16-02-003
23	STABILIZER RING	16-02-006